

Road Rod Floorboard Mounting Kit Instructions

(P/N CV6100 Silver) (P/N CV6101 Black)

Parts Included:

Front Floorboard Mount (L & R)	(4) M10x50 Cap Bolts	(4) 10MM AN FW
Rear Floorboard Mount (L & R)	(4) Spacers	(2) 1/4-20x3/4 SHCS SS

Instructions:

- 1 Do one side at a time!
- 2 Use locktite on all bolts and fasteners.
- 3 Put bike on lift, using a scissor jack underneath the engine frame cradle apply slight pressure.
- 4 Remove frame bolts (see Figure 1).
- 5 Install spacers in frame (see Figure 2).
- 6 Install corresponding rear floorboard brackets using new 10mm bolts. Retork to factory specifications. (see Figure 3).
- 7 Remove foot peg shaft, and replace with new aluminum shaft. Short one goes on the left side, and the long one goes on the right side (see Figure 4).
- 8 Install floorboards.
- 9 Use locktite on all bolts and fasteners.
- 10 Check shift pedal adjustment.
- 11 Installation Time: Approximately 1 hour or less.

Figure 1



Figure 2



Figure 3



Figure 4



All Harley Davidson® parts below are required for floorboard kit installation, and must be purchased separately

floorboard assembly (2)	P/N	50621-79A
bolt (4)	P/N	50635-82A
locknut (4)	P/N	7716

Our Warranty Policy

Vendor obligation under "Our Warranty Policy" is limited to one (1) year from date of purchase to repair or replacement of the defective item (s). Chrome, polished, powder-coated, anodized finishes, or electrical parts are limited to thirty (30) day from date of purchase.

This warranty will be void on all products that show evidence of misapplication, improper installation, abuse, lack of proper maintenance, negligence, or alteration from their original design.

The consumer will be responsible for removing from the vehicle any defective item (s), transportation costs prepaid and for reinstallation upon return by Vendor. The loss of use of the product, loss of time, inconvenience, commercial loss or consequential damages is not covered. Vendor reserves the right to change the design of any product without assuming any obligation to modify any product previously manufactured. Warranty returns of Vendor products are few because of our high quality products.

Carefully inspect all parts.... If you find that your parts arrived in damaged conditional all original packaging material (box and other materials) must be saved to make a proper damage claim within seven (7) days. You must be able to present the damaged boxes and materials to the freight carrier to verify your claim. The user shall assume all legal, personal, injury risk and liability and all other obligations, duties and risks associated therewith.