

SuperBrace

THE ULTIMATE FORK BRACE

SuperBrace Part #5192

Installation instructions

Fits Model: Harley-Davidson V-Rod

Years: (2002-2007)

1. Place motorcycle on center stand. (If your motorcycle is not equipped with a center stand, place a block device under the stand to make the motorcycle as upright as possible without it being over center.)
2. Remove any existing fork bridge or brace.
3. Remove any existing plastic fork guards (if applies).
4. Disassemble SuperBrace.
5. Loosen axle pinch bolts.

Assemble SuperBrace 1/8" below fork seals. NOTE: Should the fender prevent installing the SuperBrace at this height, place a piece of paper (such as this instruction sheet) between the SuperBrace and the fender and follow the next step.

Torque SuperBrace bolts to 10 ft. pounds. (Remove paper if used)

Re-torque axle pinch bolts to factory specification.

IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.

MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.