

## **CUSTOM LOWER AIR DAM INSTRUCTIONS**

**Installation Instructions - It will be easier to install if you first remove your Voltage Regulator to gain more room to work with.**

**Place Lower Air Dam on the Radiator Cover and use a crayon to mark the holes on the top and bottom. Once marked, take the air dam and place it aside. Using a Dremel Rotary Tool, small die Grinder or Drill to cut into the top hole, be careful with the Radiator! Then Cut a square notch just above the hole for the U-clip that's provided.**

**Remove the lower support bar by removing the 2 supporting bolts. Now drill the 2 holes that were marked earlier. Slide the U-clip in the 2 holes that were drilled. Reinstall the lower bar support and place the Air Dam on the Radiator Cover. Using the supplied bolts and fasten the air dam to the Cover!**

**A Picture guide with printed instructions comes with the Air Dam.**