

## V-Rod Led Turn Signal & Brake Strip Installation Instructions

Take off your seat and passenger Pillion, and locate the wire harness.

Cut the "Clips" that plug into your Turn Signals and Brakes in your Harness that's under your passenger seat about 2" from the clip. Mark them Left turn, Right Turn and Brake and mark which Plug they go into.

So you can Solder the New Led wires on to the stock "Clips" and plug them back into the Stock Harness! Be sure your Soldering the wires and using "heat shrink tubing" to seal the wires up so they don't get moisture in them.

**If your not familiar with these terms, we suggest you get an electrician or a mechanic that has done this before or you'll have issues down the road as vibration from riding can cause the wires to come loose if they aren't properly soldered and heat shrinked properly!**

Once you get them done just plug them back into the harness as marked and your good to go!

You will have to keep in mind if your using "Dual Element" wiring or "Eclipse Module" or "Signal Stabilizer" that needs to be wired into the leds **BEFORE** you wire them into the "Clips".

